

	POS	Codice	Descrizione	Listino
TLS4 & TLS4B Spare Parts	100	330020-745	SD Card Kit, 4G (TLS4, TLS4B)	
	200	333530-004	CPU Board Replacement Kit, EDIM, with Touch Screen (TLS4)	
	300	333530-005	CPU Board Replacement Kit, EDIM, no Screen (TLS4)	
	400	333530-006	CPU Board Replacement Kit with Touch Screen (TLS4B)	
	500	333530-007	CPU Board Replacement Kit, no Screen (TLS4B)	
	600	330020-750	USIOM Board Replacement Kit (TLS4) AC	
	700	330020-751	USIOM Board Replacement Kit (TLS4B) AC	
	800	330020-755	Replacement Cover (TLS4)	
	900	330020-764	Replacement Cover (TLS4B)	
	1000	330020-759	Replacement CPU Battery (TLS4, TLS4B)	
	1100	330020-779	Cable Kit - USIOM to CPU (TLS4, TLS4B)	
	1200	333530-016	TLS4 CPU Board - With Replacement Kit, IFSF	
	1300	333530-015	TLS4 CPU Board - No Replacement Kit, IFSF	
	1400	333530-018	TLS4B Replacement CPU IFSF, with display	
	1500	333530-017	TLS4B Replacement CPU IFSF, without display	
TLS-450 PLUS	1600	330020-793	Kit - 2 Port USB Interface Module (Comm Slot 5), TLS-450 PLUS	
	1700	330020-794	Kit - 4GB Windows FAT32 Compatible Backup Thumbdrive, TLS-450 PLUS	
	1800	330020-795	Kit - Replacement, CPU PC Board, TLS-450 PLUS (see note below)	
	1900	330020-796	Kit - Replacement, SD Card, TLS-450 PLUS	
	2000	330020-797	Kit - 3 Port Ethernet Interface Module (Comm Slot 4), TLS-450 PLUS	
	2100	330020-773	Kit - Replacement Printer, TLS-450 PLUS	
	2200	330020-774	Kit - Replacement Non-Display Door, TLS-450 PLUS	
	2300	330020-775	Kit - Replacement, Non-Printer Door, TLS-450 PLUS	
	2400	330020-772	Kit - Replacement, 8" Colour Display (Black Door), TLS-450 PLUS	
	2500	330020-809	Kit - Replacement, 8" Colour Display (Grey Door), TLS-450 PLUS	
	2600	330020-744	TLS-4xx Series OS SW Version Upgrade	
	2700	330020-828	IFSF Module for TLS-450 PLUS Upgrade Kit	
Comuni TLS-450 PLUS e TLS-450	2800	330020-613	Modulo interfaccia RS-232 (singolo)	
	2900	330020-617	Modulo interfaccia RS-232 (doppio)	
	3000	330020-618	Modulo interfaccia RS-232/RS-485	
	3100	330020-619	Modulo di interfaccia universale sensori/sonde	
	3200	330020-620	Modulo di interfaccia universale input/output	
	3300	330020-621	Pannello I/O	
	3400	330020-622	Pannello comunicazione	
	3500	330020-623	Alimentazione	
	3600	330020-624	Scheda AC Input	
	3700	330020-610	Scheda CPU	
Ricambi solo per TLS-450	3800	330020-614	Modulo interfaccia ethernet	
	3900	330020-615	Modulo interfaccia USB	
	4000	330020-616	Modulo interfaccia USB/ethernet	
	4100	330020-626	Assieme porta stampante	

	POS	Codice	Descrizione	Listino
TLS-3xx	4200	333593-001	TLS-350R / 350 Plus ECPU2 Main Board (v.34 or higher Console Software required)	
	4300	3461xx-xxx	Software centralina TLS-350R / 350 Plus - Ultimo aggiornamento versione 1	
	4400	3463xx-xxx	Software centralina TLS-350R / 350 Plus - Ultimo aggiornamento versione 3	
	4500	330728-004	TLS-350R ECPU Scheda Madre (montaggio in superficie)	
	4600	3464xx-xxx	Software centralina TLS-300 - Ultimo aggiornamento versione 4	
	4700	329367-006	Gruppo sportello TLS-350R (con collegamenti elettrici)	
	4800	329367-016	Gruppo sportello TLS-350 Plus (con collegamenti elettrici)	
	4900	329367-001	Gruppo sportello TLS-350 (con collegamenti elettrici)	
	5000	329367-008	Gruppo sportello TLS-PC (con collegamenti elettrici)	
	5100	330027-001	Gruppo sportello TLS-300 (con collegamenti elettrici)	
	5200	330027-004	Gruppo sportello TLS-PC 300 (con collegamenti elettrici)	
	5300	329328-002	Gruppo tastiera	
	5400	330734-001	Alimentatore DC PCB (TLS-350)	
	5500	330051-003	Alimentatore DC PCB (TLS-300)	
	5600	576007-115	Prese trasformatore 220-240 Volts (TLS-350)	
	5700	331190-003	Modulo AC Input 230 Volts (TLS-350)	
	5800	330039-001	PCB 8 Sonde TLS-300	
	5900	330513-001	PCB 2 sonde, 8 sensori TLS-300C	
	6000	330230-001	PCB 4 sonde, 8 sensori TLS-300	
	6100	331758-001	PCB 8 sonde, 8 sensori TLS-300	
	6200	332067-001	PCB 6 sonde, 8 sensori, 5 VGW TLS-300	
	6300	332209-005	PCB 8 sonde, 8 sensori, 8 Tipo A TLS-300	
	6400	329370-004	Gruppo sportello stampante TLS	
	6500	329348-001	Scheda interfaccia stampante locale (TLS-350 CPU)	
	6600	329257-001	Scheda madre - TLS-350R / 350 Plus / 350	
	6700	329263-002	Collegamento PCB	
	6800	329372-001	24 bottoni per keypad	
	6900	576010-695	Batteria di Back-Up CPU 3.5 Volt	
7000	576006-786	Modulo connessioni 10 posizioni, Relay TLS-300 I/O		
TLS 2	7100	331763-001	Alimentatore TLS2	
	7200	576011-070	Display con touch Panel (dopo 2007)	
	7300	332769-004	Scheda CPU TLS2	
	7400	332951-002	Scheda CPU TLS2P	